




INSTALLATION INSTRUCTIONS FOR
ALPACO CLASSIC PARTITIONS




PILASTER/WALL

ASSEMBLY

- A. Verify that the pilasters are both plumb and level before continuing.
- B. Fasten pilaster to wall bracket using through-bolts.

HARDWARE LIST

PICTURE	DESCRIPTION	QTY
	#12 x 2.5" WALL SCREW	6
	RED PLASTIC SHIELD	6
	"U" BRACKET	1
	#10-24 x 3/8" NUT	6
	#10-24 x 1/2" BOLT	6



PILASTER/ PANEL ALCOVE






ASSEMBLY


- A. For the perpendicular pilaster between two "U" brackets (the tee configuration), first use a through-bolt through the two "U" brackets to fasten the pilaster to the wall panel.

- B. If a standalone alcove is present, the tee configuration is replaced by two alcove brackets (Figure A).

Note: For door details, see pages 8 and 9.

HARDWARE LIST

PICTURE	DESCRIPTION	QTY
	#10-24 x 3/8" NUT	24
	#10-24 x 1/2" BOLT	24
	#12 x 2.5" WALL SCREW	12
	RED PLASTIC SHIELD	12
	"U" BRACKET	4



DOOR HARDWARE

ASSEMBLY - INSWING

- A. Doors with a width of at least 32” require 4 hinges.
- B. The bottom hinge is not cammed.
- C. Before hanging the door on its hinges, the pinned half of the hinge should be fastened to the door with its pin facing down, and the mating half of the hinge should be fastened to the pilaster.
- D. Drill for the coat hook with a #19 drill bit to a depth of 7/16”. **Correct hole diameter and depth is critical.**

<u>HARDWARE LIST</u>		
PICTURE	DESCRIPTION	QTY
	HINGE ASSEMBLY WITH COVER PLATE (CAMMED)	2
	HINGE ASSEMBLY WITH COVER PLATE (NOT CAMMED)	1
	#10 x 7/16” HINGE SCREWS	18
	COAT HOOK WITH TWO SCREWS	1

Note: please see pages 11 and 12 for hinge and latch installation details, respectively.





FIGURE A




DOOR HARDWARE

ASSEMBLY - OUTSWING

- A. Doors with a width of at least 32" require 4 hinges.
- B. Install additional door bumper on the outside of the door as required.
- C. The bottom hinge is not cammed.
- D. **Drill holes to align for door handle and install door handle with both spacers on the inside of the compartment.**
- E. The holes for the coat hook should be drilled to a depth of 7/16" with a #19 drill bit.


Note: please see pages 11 and 12 for hinge and latch installation details, respectively.



HARDWARE LIST

PICTURE	DESCRIPTION	QTY
	HINGE ASSEMBLY WITH COVER PLATE (CAMMED)	2
	HINGE ASSEMBLY WITH COVER PLATE (NOT CAMMED)	1
	#10 x 0.4375" HINGE SCREWS	18
	COAT HOOK WITH TWO SCREWS	1
	DOOR HANDLE WITH TWO SPACERS	1

FIGURE A









URINAL SCREEN

ASSEMBLY

- A. Before proceeding, confirm that the backing of the wall is adequate to support the mounting of urinal screens. Check shop drawings for layout.
- B. Insert plastic shields into the walls and secure wall brackets with 2.5" wall screws.
- C. Place urinal screen on a support device at desired height.
- D. Drill holes through the urinal screen to facilitate through-bolts. Set the urinal screen into wall brackets and fasten.







HARDWARE LIST


PICTURE	DESCRIPTION	QTY
	#12 x 2.5" WALL SCREW	4
	RED PLASTIC SHIELD	4
	U/S "U" BRACKET	1
	#10-24 x 3/8" NUT	4
	#10-24 x 1/2" BOLT	4



LATCH
ASSEMBLY

HARDWARE LIST

PICTURE	DESCRIPTION	QTY
	INDICATOR COVER WITH INSERT	1
	CENTER SHAFT	1
	INDICATOR DIAL	1
	INDICATOR DIAL PLACEMENT SLEEVE	1
	LATCH HANDLE	1
	#10-24 x 1/2" BOLT	2




HINGE

ASSEMBLY

A. Cams are preset at an angle of 0°. When the cam is inserted, this means that the notch on the cam meets up with the notch on the lower half of the hinge.

B. If changing the angle, turn the cam one notch for every 15°.


Note: the bottom hinge of each set of door hinges will not be cammed.



HARDWARE LIST

PICTURE	DESCRIPTION	QTY
	LOWER HALF OF HINGE WITH CAM INSERT	1
	UPPER HALF OF HINGE	1
	#10 x 7/16" HINGE SCREWS	6
	COVER PLATE	2

FIGURE A



CARE AND MAINTENANCE OF **BATHROOM PARTITIONS**

In order to provide bathroom partitions with proper care and maintenance, the following instructions must be followed:

- A. All surfaces must be kept clean with water and a mild soap solution only.
- B. In areas of high humidity, the rooms must be properly ventilated.
- C. “Hosing down” or wet-washing of these units may cause water adsorption and damage.
- D. For maximum protection, periodic application of any standard furniture wax will be beneficial.

WARNING

Under no circumstances should these components be subjected to:

- Abrasive powders or pads
- Bathroom cleaners
- Ceramic tile cleaners
- Solutions containing more than 1% by volume of ammonia
- Solutions containing acids or lye
- Solutions containing enzymes

Attention to work progress during new construction or renovation is paramount.

Some cleaning services may use agents for ceramics and tiles that will damage these components.